



Dell Inspiron 1545 Optical Disk Drive Replacement

The Optical Disk Drive is the part of the laptop that allows you to read and write to disks.

Written By: Nathan Lemay



INTRODUCTION

This guide will be utilized if you are having issues with reading disks and it is not a firmware problem.




TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Spudger](#) (1)




PARTS:

- [Dell Inspiron 1545 Optical Drive](#) (1)
-



Step 2




Step 3



- Slide the battery out of the battery bay.

Step 4 — Optical Disk Drive



- Flip the laptop to its back side.
- Remove the screw (5mm Phillips #1) that secures the Optical Disk Drive on the back of the laptop.

Step 5



- Push the Optical Disk Drive out using a spudger tool as shown and pulling from the front cover of the Optical Disk Drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 11:36:59 PM.